

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### BMW 318i

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove air box.
2. Clamp RAMPOD to Air Flow Meter using the hose provided.
3. Attach the RAMPOD bracket to mounting points on inner guard.
4. Push temp sensor into hole provided in the RAMPOD trumpet. (Only on some models.)
5. Check all nuts and bolts are tight and all plugs are plugged in.
6. You are now ready to start the engine.
7. ENJOY



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)