



BMW R850/1100/1150 GS
Part No. NU 7302KIT

WARNING –FILTER FOAM(S) MUST BE OILED PRIOR TO USE.

FITTING INSTRUCTIONS

1. Remove original paper air filter from bike and replace with Unifilter foam element.
2. Insert pre-filter sock into front end of air box snorkel. Leave approximately five centimetres protruding.
3. Roll this section back over the intake snorkel and secure with the provided cable-tie. Re-assemble the bike and go out and get it dirty!

SERVICING & RE-OILING

Inspect the pre-filter every 2,500kms and clean or change as necessary. Likewise, inspect the main filter every 5,000kms and clean as necessary. Inspect more often in dusty conditions.

Wash filter foams in **mineral turps**, pad dry with a soft, absorbent cloth and re-oil. Conventional filter oils such as Unifilter's "*Filter Fix*" or Belray are recommended.

Made in Australia by

UNIFILTER AUSTRALIA

1/35 Leighton Place
Hornsby NSW 2077

Tel: (02) 9482 1792, Fax (02) 9482 1790
www.unifilter.com.au