

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Ford Falcon BA XR8

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove air box and air box ducting.
2. Clamp RAMPOD into the intake hose.
3. Attach the RAMPOD brackets to the air box mounting points (the short extension brackets may need to be bent slightly).
4. Attach the RAMPOD foam to the RAMPOD.
5. Check all clamps, nuts and bolts are tight.
6. You are now ready to start the engine.
7. ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au