

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Ford Falcon ED-AU XR6-XR8

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove air box.
2. Bolt RAMPOD adapter to the air flow meter (XR8) or the air box adapter plate (XR6).
3. Attach the RAMPOD bracket to air box mounting points (on some models) or drill two 6.5mm holes in the inner guard and bolt the bracket to them.
4. Attach the RAMPOD foam to the trumpet.
5. Check all clamps, nuts and bolts are tight.
6. You are now ready to start the engine.
7. ENJOY



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)