

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Ford Focus

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove air box.
2. Clamp RAMPOD to air flow meter.
3. Attach the RAMPOD bracket to the engine bay bracing in front of the fuse box
4. Attach the RAMPOD foam to the trumpet.
5. Check all clamps, nuts and bolts are tight.
6. You are now ready to start the engine.
7. ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au