

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Ford Falcon BA XR6/Turbo & 220KW V8 Custom Induction Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove the lid of the air box.
- 2 Remove air box and ducting from the radiator support panel.
- 3 Remove the flexible intake hose.
- 4 Clamp the new intake pipe to the intake cross over pipe.
- 5 Clamp the RAMPOD to the intake pipe.
- 6 Attach the RAMPOD bracket to the inner guard using the bolt supplied. Use the 7mm hole that already exists. On some models this used to attach some electrical cabling.

Heat Shield Fitting Instructions

- 7 Bolt the small right angle bracket supplied to the inner guard using the earth strap hole and bolt.
- 8 Place the heat shield over the RAMPOD and attach the shield to the air box mounting point on the strut tower and to the small right angle bracket. (The front of the heat shield should slide under the radiator support panel).
- 9 Check all the nuts, bolts and clamps are tight.
- 10 You are now ready to start the engine.
- 11 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au