

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Holden Astra Turbo

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove air box.
2. Clamp joiner hose and RAMPOD into intake hose.
3. Attach the RAMPOD bracket to the air con hose mounting point under the air box. (The optional heat shield also uses this point for attachment).
4. Check all clamps, nuts and bolts are tight.
5. You are now ready to start the engine.
6. ENJOY



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)