

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Holden Commodore 5.0L V8

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove air box.
2. Clamp RAMPOD into intake hose. (AFM on VT).
3. Attach the RAMPOD bracket to air box mounting points.
4. Push temp sensor into hole provided in the RAMPOD trumpet. (VT)
5. Check all clamps, nuts and bolts are tight.
6. You are now ready to start the engine.
7. ENJOY



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)