

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Holden Commodore Ecotec V6

Note – It is preferable to fit your RAMPOD kit when the motor is cold.

1. Remove engine cover.
2. Remove air box and air box ducting.
3. Unplug and remove MAF sensor
4. Remove intake hose from throttle body.
5. Clamp new intake pipe to throttle body with rubber hose provided.
6. Clamp MAF to intake pipe using rubber hose provided.
7. Clamp RAMPOD to MAF and attach the RAMPOD.
8. Using the RAMPOD bracket, mark a point on the inner guard for drilling the hole for the bolt to hold the bracket.
9. Drill a 7mm hole where you placed the mark.
10. Bolt the RAMPOD bracket to the inner guard using the bolt provided.
11. Push temperature sensor into the hole provided in the RAMPOD.
12. Check all clamps, nuts and bolts are tight and all plugs are plugged in.
13. You are now ready to start the engine.
14. ENJOY



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)