

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Holden Commodore – VL – RB30 & RB30 Turbo

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and ducting from vehicle.
- 2 Unplug and remove air flow meter (AFM).
- 3 Attach RAMPOD to AFM using the bolts supplied.
- 4 Clamp RAMPOD and AFM back into intake hose.
- 5 Bolt RAMPOD bracket to air box mounts on the inner guard.
- 6 Plug in air flow meter.
- 7 Check all clamps, nuts and bolts are tight.
- 8 You are now ready to start the engine.
- 9 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au