

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Holden GEN3 Commodore, Monaro & Pontiac GTO LS1 Custom Induction Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove the radiator shroud for easier access.
- 2 Remove air box and ducting from the vehicle.
- 3 Unplug and remove MAF sensor.
- 4 Remove intake hose from the throttle body.
- 5 Clamp new intake pipe to the throttle body with the rubber hose provided.
- 6 Clamp MAF to intake pipe using rubber hose provided.
- 7 Clamp RAMPOD to MAF and attach the RAMPOD bracket to the studs that held the air box in place.
- 8 Check all clamps, nuts and bolts are tight and all plugs are plugged in.
- 9 You are now ready to start the engine.
- 10 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au