

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Holden Commodore VT S2 Incl Monaro 2003/04 Pontiac GTO GEN3 Big Bore MAF Pipe Kit

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove engine cover.
- 2 Remove air box and MAF pipe from the vehicle.
- 3 Remove the three air box mounting lugs and replace with the three rubber mounts supplied.
- 4 Bolt the air box back in place.
- 5 Clamp the new MAF pipe to the throttle body and MAF sensor.
- 6 Check all clamps, nuts and bolts are tight.
- 7 Replace engine cover.
- 8 You are now ready to start the engine.
- 9 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au