

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Holden Monaro LS1 Series 2 Custom Induction Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove the radiator shroud for easier access.
- 2 Remove air box and ducting from the vehicle.
- 3 Unplug and remove MAF sensor.
- 4 Remove intake hose from the throttle body.
- 5 Clamp new intake pipe to the throttle body with the rubber hose provided.
- 6 Clamp MAF to intake pipe using rubber hose provided.
- 7 Clamp RAMPOD to MAF and bolt the RAMPOD bracket to the hole in the inner guard and stud that held the air box in place.
- 8 Push temperature sensor into the hole provided in the MAF pipe.
- 9 Check all clamps, nuts and bolts are tight and all plugs are plugged in.
- 10 You are now ready to start the engine.
- 11 ENJOY



## UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)