

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Honda Civic 02-04 Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and ducting from the vehicle.
- 2 Clamp new intake pipe to the throttle body using the hose and clamps provided.
- 3 Attach the RAMPOD to the intake pipe.
- 4 Bolt the RAMPOD brackets to the original air box mounting points.
- 5 Attach the breather hose supplied to the intake and slide the other end into the original rocker cover breather hose.
- 6 Check all clamps, nuts and bolts are tight.
- 7 You are now ready to start the engine.
- 8 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au