

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Hyundai Accent & Excel

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and ducting from the vehicle.
- 2 Clamp RAMPOD into the intake hose.
- 3 Attach the RAMPOD bracket to the strut tower using the small bracket supplied (Accent only). Bolt to the strut tower using the mounting point of the fuse box bracket.
- 4 Clamp the RAMPOD foam to the trumpet. (Excel uses angled RAMPOD foam).
- 5 Check all clamps, nuts and bolts are tight.
- 6 You are now ready to start the engine.
- 7 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au