

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Mazda 6 '03-'05

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Disconnect the battery.
- 2 Remove the air flow meter from the air box.
- 3 Remove the air box.
- 4 Clamp the short section of 70mm pipe provided to the intake hose.
- 5 Clamp the RAMPOD to the 70mm pipe.
- 6 Attach the RAMPOD brackets to the air box mounting bracket
- 7 Screw the air flow meter into the RAMPOD.
- 8 Check all nuts and bolts are tight.
- 9 Reconnect the battery.
- 10 You are now ready to start the engine.
- 11 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au