

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Mazda MX5/Miata 1.8L

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Disconnect air flow meter plug and temperature sensor (NB models).
- 2 Remove the air box and air flow meter from the vehicle.
- 3 Clamp RAMPOD to air flow meter.
- 4 Clamp air flow meter back into the intake hose.
- 5 Attach the RAMPOD bracket to the air box mounting points.
- 6 Push temperature sensor into the hole provided in the RAMPOD trumpet.
- 7 Check all the clamps, nuts and bolts are tight, and that the air flow meter is plugged in.
- 8 You are now ready to start the engine.
- 9 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au