

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Mazda MX5/Miata/Eunos Roadster Custom Induction Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and ducting from the vehicle.
- 2 Unplug and remove air flow meter and temperature sensor.
- 3 Remove intake hose from the throttle body and disconnect rocker cover breather from intake hose.
- 4 Clamp new intake pipe to the throttle body with the rubber hose provided and reconnect the rocker cover breather hose.
- 5 Clamp air flow meter to intake pipe using rubber hose provided.
- 6 Clamp RAMPOD to air flow meter and attach the RAMPOD bracket to the studs that held the air box in place.
- 7 Push temperature sensor into the hole provided in the RAMPOD.
- 8 Check all nuts and bolts are tight and all plugs are re-seated.
- 9 You are now ready to start the engine.
- 10 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au