

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Mini Cooper S RAMPOD Kit with Heatshield

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove the air box lid and filter.
- 2 Attach the heat shield to the base of the air box using the screws provided. They attach to the two front screw points on the air box base. The heat shield also attaches to the plastic panel at the back of the engine bay using the original screw.
- 3 Attach the power box to the bracket on the side of the heat shield.
- 4 You can now place the RAMPOD into the intake hose and tighten the clamp.
- 5 Check all the clamps, nuts and bolts are tight.
- 6 You are now ready to start the engine.
- 7 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au