

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Mitsubishi FTO

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and air box ducting.
- 2 Clamp RAMPOD into standard intake hose.
- 3 Attach the Rampod bracket to the air box mounting points.
- 4 Check all the clamps, nuts and bolts are tight.
- 5 You are now ready to start the engine.
- 6 ENJOY.



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au