

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Mitsubishi Mirage/Lancer 1.5L

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and air box ducting.
- 2 Clamp RAMPOD and joiner hose into standard intake hose.
- 3 Attach the RAMPOD bracket to the charcoal canister mounting points on the strut tower.
- 4 Check all clamps, nuts and bolts are tight.
- 5 You are now ready to start the engine.
- 6 ENJOY.



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au