

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Nissan Pulsar N14, N15, N16, NXR & SSS

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove the air box.
- 2 Attach large bracket supplied to RAMPOD.
- 3 Locate RAMPOD in engine bay with RAMPOD flange loosely bolted to air flow meter.
- 4 Mark for drilling a 6mm hole on the strut tower.
- 5 Remove RAMPOD and drill hole.
- 6 Replace RAMPOD and tighten all bolts, mounting bracket to strut tower.
- 7 Re-check all nuts and bolts.
- 8 You are now ready to start the engine.
- 9 ENJOY!



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)