

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Nissan Silvia 240SX - NA

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and ducting from the vehicle.
- 2 Unplug and remove air flow meter.
- 3 Attach RAMPOD to air flow meter using the bolts supplied.
- 4 Place air flow meter and RAMPOD back into intake hose.
- 5 Bolt RAMPOD bracket to air box mounts on the inner guard.
- 6 Plug in the air flow meter
- 7 Check all the nuts, bolts and clamps are tight.
- 8 You are now ready to start the engine.
- 9 ENJOY



### UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)