

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Nissan Skyline R32 GT, GTS, GTSt & GTS4

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and air box ducting.
- 2 Bolt RAMPOD to air flow meter.
- 3 Attach the RAMPOD bracket to air box mounting points. (Note – air flow meter may need to be rotated slightly).
- 4 Check all the clamps, nuts and bolts are tight.
- 5 You are now ready to start the engine.
- 6 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au