

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Nissan Skyline R33, R34-GT, GTS, GTSt & GTS4

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box.
- 2 Bolt RAMPOD flange to the air flow meter using the bolts provided. (Note - some models require the air flow meter to be rotated slightly for better fitment.)
- 3 Attach RAMPOD bracket to the inner guard.
- 4 Check all nuts, bolts and clamps are tight.
- 5 You are now ready to start the engine.
- 6 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au