

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Nissan Skyline R33 - RB25T

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove the air box and air flow meter from the vehicle.
- 2 Remove the air flow meter from the air box.
- 3 Bolt RAMPOD flange to the air flow meter using the bolts provided.
- 4 Attach the bracket to the RAMPOD and air flow meter.
- 5 Bolt the bracket to the inner guard using the bolt provided. Remove the plastic splash guard clip on the inner guard and bolt the bracket using this hole.
- 6 Check all nuts, bolts and clamps are tight.
- 7 You are now ready to start the engine.
- 8 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au