

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Non-Turbo Subaru Liberty & Impreza RX – '94-'98

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove airbox from vehicle.
- 2 Attach main bracket to RAMPOD.
- 3 Fit RAMPOD to airflow meter using bolts supplied.
- 4 Attach supplied feet (and extensions if required) to bottom of main bracket. If no existing bolt holes line up, you may need to mark and drill 2 x 6mm holes.
- 5 Bolt the whole assembly in place.
- 6 Re-check all bolts and nuts are tight.
- 7 You are now ready to start the engine.
- 8 Enjoy!



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au