

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Subaru WRX 01-04 Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air flow meter from the lid of the air box. **Do not unplug it.**
- 2 Remove air box from vehicle.
- 3 Undo the 10mm nut on the inner guard holding air box ducting in place.
- 4 Remove the front, right wheel.
- 5 Remove the splash guard from the wheel arch.
- 6 Feed the intake pipe through the hole in the inner guard where the air box ducting went through.
- 7 Bolt the intake pipe to the inner guard.
- 8 Clamp the RAMPOD to the intake pipe using the joiner hose provided.
- 9 Place the splash guard back into the wheel arch and tighten the clips.
- 10 Replace the front, right wheel.
- 11 Tighten the clamp on the rubber intake hose.
- 12 Place the air flow meter into the intake pipe and tighten the screws.
- 13 Re-check all screws and clamps are tight.
- 14 You are now ready to start the engine.
- 15 Enjoy!



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au