

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Subaru WRX '97-'00

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Disconnect air flow meter plug.
- 2 Remove air box and air flow meter from the vehicle .
- 3 Bolt RAMPOD to air flow meter.
- 4 Clamp air flow meter back into the intake hose.
- 5 Attach the RAMPOD bracket to studs on the inner guard.
- 6 Check all nuts and bolts are tight and that all plugs are firmly re-seated.
- 7 You are now ready to start the engine.
- 8 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au