

# UNIFILTER

## RAMPOD KIT INSTRUCTIONS

### Toyota Celica '99-05 Custom Induction Intake

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Disconnect battery.
- 2 Remove air flow meter from the top of the air box.
- 3 Remove vacuum lines and sensor from the air box.
- 4 Remove the air box and air box ducting from the vehicle.
- 5 Remove ECU air duct from the vehicle - it simply clips out - **Do not open ECU box.**
- 6 Fit 1" flexible hose to ECU box and to the radiator shroud using the cable ties provided.
- 7 Push vacuum line end-cap provided to the vacuum nipple on the intake manifold.
- 8 Clamp intake to the throttle body.
- 9 Fit the intake bracket to the intake and attach it to the throttle body linkage bolts.
- 10 Place the air flow meter into the intake and tighten the screws provided.
- 11 Attach the RAMPOD foam and cage.
- 12 Check all the nuts, bolts and clamps are tight.
- 13 Reconnect the battery.
- 14 You are now ready to start the engine.
- 15 Enjoy.



## UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: [info@uniflow.com.au](mailto:info@uniflow.com.au)

Web: [www.unifilter.com.au](http://www.unifilter.com.au)