

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Toyota Echo 02-04, Mazda Protégé 00-04

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air flow meter from air box.
- 2 Remove air box.
- 3 Clamp RAMPOD into intake hose.
- 4 Attach RAMPOD brackets to air box mounting plate using the small angle brackets provided.
- 5 Place air flow meter into the RAMPOD using the screws provided.
- 6 Cable tie the vacuum line to the black RAMPOD bracket.
- 7 Check all nuts and bolts are tight and that all plugs are firmly re-seated.
- 8 You are now ready to start the engine.
- 9 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au