

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Toyota MR2 Custom Induction Intake

- 1 Remove air flow meter from air box.
- 2 Remove air box.
- 3 Clamp the 70mm intake pipe supplied into intake hose.
- 4 Place air flow meter into the RAMPOD using the screws provided.
- 5 Attach the RAMPOD foam to the RAMPOD.
- 6 Place the RAMPOD into the cavity behind the radiator support panel and attach the RAMPOD to the intake pipe using the support straps supplied.
- 7 Attach the straps to the original air box mounting points
- 8 Reconnect the air flow meter.
- 9 Check that all clamps, nuts and bolts are tight.
- 10 You are now ready to start the engine.
- 11 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au