

UNIFILTER

RAMPOD KIT INSTRUCTIONS

Holden VZ SV6

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

- 1 Remove air box and radiator shroud from the vehicle.
- 2 Clamp RAMPOD to air flow meter using the hose provided.
- 3 Attach the RAMPOD bracket to the radiator support panel next to the head light.
- 4 Check all clamps, nuts and bolts are tight.
- 5 Place the radiator shroud back into position.
- 6 Some models need the ECU to be reset. Disconnect the battery for 30 minutes then reconnect it. The ECU should now be reset.
- 7 You are now ready to start the engine.
- 8 ENJOY



UNIFILTER AUSTRALIA

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ +61 2 9482 1792, 📠 +61 2 9482 1790

Email: info@uniflow.com.au

Web: www.unifilter.com.au