AUSTRALIA

KTM 2013 1190 Adventure/Adventure R. Part# AU 1429 KIT.

Kit includes:

Replacement Two Stage Panel Filter, 2 x Intake Snorkel Pre-cleaners & 1 x Soft Foam Air Box Seal.

Fitting instructions.

Remove fairings and fuel tank as per your owners manual.



Complete Kit



Main Filter Fitted

Place main filter in position. Make sure the filter is seated properly at the base of the air box and close Secure the retaining clip. This is firm to close. (We recommend using a small amount of grease on the sealing edge of the filter combat any warpage in the plastic air box)



Soft Foam Air Box Seal



Soft Foam Air Box seal Fitted

Push the air box screws through the air box lid and the dust seal. Attach the rear engine breather hose and screw the lid evenly to the base. Do not over tighten.

Push snorkel intake pre-cleaners into snorkels and fold over the end. Use the plastic grid to secure.



Snorkel Pre-Cleaner



Snorkel Pre-Cleaner Front



Snorkel Pre-Cleaner secured by Factory Plastic Grid



