UNIFILTER

RAMPOD KIT INSTRUCTIONS

Honda Civic, CRX, Integra, Accord & Prelude

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

1 Remove air box and ducting from the vehicle.
2 Clamp RAMPOD to intake tube.
3 Attach the RAMPOD bracket to the air box mounting points.
4 Check all clamps, nuts and bolts are tight.
5 You are now ready to start the engine.
6 ENJOY

UNIFILTER AUSTRALIA
1/35 Leighton Place, Hornsby NSW 2077, Australia
☎ +61 2 9482 1792, 🖷 +61 2 9482 1790
Email: info@uniflow.com.au
Web: www.unifilter.com.au