UNIFILTER

RAMPOD KIT INSTRUCTIONS

Nissan Silvia 200SX - S14 & S15

Note – It is preferable that you fit your RAMPOD kit when the motor is cold.

1 Remove air box.

2 Bolt RAMPOD flange to the air flow meter using the bolts provided. (Note - some models require the air flow meter to be rotated slightly for better fitment.)

3 Attach RAMPOD bracket to the inner guard.

4 Check all nuts, bolts and clamps are tight.

5 You are now ready to start the engine.

6 ENJOY

UNIFILTER AUSTRALIA
1/35 Leighton Place, Hornsby NSW 2077, Australia
☎ +61 2 9482 1792, 🖷 +61 2 9482 1790
Email: info@uniflow.com.au
Web: www.unifilter.com.au